

HINWEIS

Das Produkt funktioniert bei allen Fernsehgeräten, die eine Maus- und Tastaturfunktion unterstützen. Bitte wenden Sie sich bei Fragen zur Kompatibilität an Ihren Fernsehgerätehersteller.
Aufgrund der Vielfalt an Fernsehgeräten und der darauf installierten Firmware und Apps kann keine 100%ige Kompatibilität zu jedem Zeitpunkt garantiert werden

Samsung

2012 Modelle

- Samsung Series 5 EH5300
- Samsung Series 5 ES5400
- Samsung Series 5 ES5410
- Samsung Series 5 ES5500
- Samsung Series 5 ES5700
- Samsung Series 6 ES6100
- Samsung Series 6 ES6300
- Samsung Series 6 ES6340
- Samsung Series 6 ES6570
- Samsung Series 6 ES6710
- Samsung Series 6 ES6800
- Samsung Series 6 ES6900
- Samsung Series 8 ES8000

2013 Modelle

- UE55F9000SLXXN
- UE65F9000SLXXN
- UE55F8500SLXXN
- UE65F8000SLXXN
- UE55F8000SLXXN
- UE46F8000SLXXN
- UE40F8000SLXXN
- UE60F7000SLXXN
- UE46F7000SLXXN
- UE40F7000SLXXN
- UE55F6400AWXXN
- UE50F6400AWXXN
- UE46F6400AWXXN
- UE40F6400AWXXN
- UE32F6400AWXXN
- UE50F6200AWXXN
- UE46F6200AWXXN
- UE40F6200AWXXN
- UE32F6200AWXXN
- UE50F5700AWXXN
- UE46F5700AWXXN
- UE42F5700AWXXN
- UE32F5700AWXXN
- UE39F5700AWXXN
- UE50F5500AWXXN
- UE46F5500AWXXN
- UE39F5500AWXXN
- UE32F5500AWXXN
- UE42F5500AWXXN

- UE22F5410AWXXN
- UE22F5400AWXXN
- UE42F5300AWXXN
- UE32F5300AWXXN
- UE39F5300AWXXN
- UE46F5300AWXXN
- UE32F4510AWXXN
- UE40F6740SSXXN
- UE55F6670SSXXN
- UE50F6670SSXXN
- UE46F6670SSXXN
- UE40F6670SSXXN
- UE55F6650SSXXN
- UE46F6650SSXXN
- UE40F6650SSXXN
- UE55F6640SSXXN
- UE50F6640SSXXN
- UE46F6640SSXXN
- UE40F6640SSXXN
- UE55F6510SSXXN
- UE46F6510SSXXN
- UE40F6510SSXXN
- UE32F6510SSXXN
- UE55F6500SSXXN
- UE50F6500SSXXN
- UE46F6500SSXXN
- UE40F6500SSXXN
- UE75F6400AWXXN
- UE65F6400AWXXN
- UE55F6400AWXXN
- UE46F6400AWXXN
- UE40F6400AWXXN
- UE32F6400AWXXN
- UE55F6320AWXXN
- UE46F6320AWXXN
- UE40F6320AWXXN
- UE60F6300AWXXN
- UE46F6200AWXXN
- UE40F6200AWXXN
- UE32F6200AWXXN
- UE50F5700AWXXN
- UE46F5700AWXXN
- UE42F5700AWXXN
- UE32F5700AWXXN
- UE39F5700AWXXN
- UE50F5500AWXXN
- UE46F5500AWXXN
- UE39F5500AWXXN
- UE32F5500AWXXN
- UE42F5500AWXXN

2014 Modelle

- UE75HU7500LXXN
- UE65HU7500LXXN
- UE55HU7500LXXN
- UE48HU7500LXXN

- UE55HU6900SXXN
- UE50HU6900SXXN
- UE40HU6900SXXN
- UE85S9SLXXN
- UE78HU8500LXXN (Curved)
- UE65HU8500LXXN (Curved)
- UE55HU8500LXXN (Curved)
- UE65H8000SLXXN (Curved)
- UE55H8000SLXXN (Curved)
- UE48H8000SLXXN (Curved)
- UE50H6200AWXXN
- UE48H6200AWXXN
- UE40H6200AWXXN
- UE32H6200AWXXN
- UE22H5610AWXXN
- UE22H5600AWXXN
- UE48H5570SSXXN
- UE40H5570SSXXN
- UE32H5570SSXXN
- UE65HU8200L
- UE55HU8200L
- UE55HU7200S
- UE65HU7100S
- UE55HU7100S
- UE55H6850A
- UE48H6850A
- UE55H6800A
- UE48H6800A
- UE85HU7500L
- UE65HU7200S
- UE55HU7200S
- UE65HU7100S
- UE55HU7100S
- UE60H7000SL
- UE55H7000SL
- UE46H7000SL
- UE40H7000SL
- UE55H6700SL
- UE48H6700SL
- UE40H6700SL
- UE55H6650SL
- UE48H6650SL
- UE48H6640SL
- UE40H6650SL

- UE55H6640SL
- UE40H6640SL
- UE55H6500SL
- UE48H6500SL
- UE40H6500SL
- UE55H6410SS
- UE48H6410SS
- UE40H6410SS
- UE32H6410SS
- UE75H6400AW
- UE65H6400AW
- UE55H6400AW
- UE50H6400AW
- UE48H6400AW
- UE40H6400AW
- UE48H6240A
- UE40H6240A
- UE60H6230A
- UE55H6230A
- UE60H6203A
- UE55H6203AW
- UE46H6203AW
- UE40H6203AW
- UE60H6200AW
- UE55H6200AW
- UE48H5510S
- UE40H5510S
- UE50H5500AW
- UE48H5500AW
- UE40H5500AW
- UE32H5500AW
- UE46H5303AW
- UE40H5303AW
- UE32H5303AW
- UE58H5203A
- UE48H5203A
- UE40H5203A

2014 & 2015 Modelle

- J5550 (5er, 6er-Serie, no J5150)
- H6270 (6er, 7er, 8er-Serie)

xx53822/04.16

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

Grundig

Modelle

42 VLE9380 SL
 46 VLE880
 32 VLE8230 WL
 55 VLE9380 SL
 40 VLE 7320 BL
 40 VLE7321 BL
 39 CLE2525 BL
 32 VLE8120 BG
 55 FLE9170 SL
 42 VLE9474 SL
 39 VLE941
 40 VLE8221 BL

LG Electronics

2012 Modelle

47LA7909
 50PH6608
 47LA7408
 60PH6608
 32LA6208
 50PH6708
 47LA6418
 42LA6418
 55LA6608
 47LA6136
 32LA6678
 42LN5758
 55LA7408
 42LA6208
 32LA6608
 50LN5758
 42LA6678
 29LN450
 32LN5758
 42LA6918
 42LN5700
 32LN5403
 47LA6678
 47LA8609
 60LA8609
 55LA6678
 47LA6208

55LA7909
 55LA6918
 50LA6608
 55EA9809
 42LA6928
 32LA6130
 47LA6918
 42LA8609
 42LA620S
 55LA6418
 42LN5778
 55LA6208
 55LA9709
 32LN5778
 55LN5758
 84LM960V
 47LM765S
 55LM649S
 60PZ955S
 50PZ755S
 55LM765S
 42LA6608
 47LA6608
 42LV5590
 37LV579S
 72LM950V
 55LM660S
 55LM640S
 39LN5758
 47LB630V
 50LA6208
 32LB580V
 50LN5708
 50LB671V
 60LA6208
 32LB560V
 47LN5708
 39LB570V
 65LA9709
 42LD320B
 47LN5778
 42LB731V
 60LN5758
 60LB650V
 55LB671V
 47LB730V
 42LB630V

42LB671V
 47LN5758
 55LB630V
 32LB5610
 39LB650V
 50LB650V
 55LA9659
 47LB671V
 28LB450U
 60LB870V
 42LA4708
 47LN5778
 42LB730V
 42LB650V
 42LN5708
 47LB731V
 55LB731V
 55LB670V
 55EA8809
 55LB650V
 55EA9709
 55LB870V
 60LB580V
 65LA9659

Loewe

Modelle

Connect ID 55
 Connect ID 46/DR+
 Connect ID 40
 Connect ID 46
 Connect ID 32
 Connect ID 40 DR+
 Art 40

Panasonic

Modelle

TX-L42E6E
 TX-L47E5E
 TX-L50BLW6
 TX-L50BLW6
 TX-P50X60E
 TX-P42X60
 TX-L42EW6K
 TX-L39EW6K
 TX-L39EW6W
 TX-L42E5E
 TX-L42EW6S
 TX-L39BLW6
 TX-L32BLW6
 TX-L55ETW60
 TX-L42ETW60
 TX-L47ETW60
 TX-L50ETW60
 TX-L50DTW60
 TX-L55DTW60
 TX-L60DTW60
 TX-L24XW6
 TX-L42DTW60
 TX-L47DTW60
 TX-39ASW604
 TX-24ASW504
 TX-42ASW604W
 TX-42ASW654
 TX-47ASW654
 TX-55ASW654

Philips

Modelle

50PFL5038K/12
32PFL4508K/12
47PFL7008K/12
42PFL6008K/12
46PFL3218K
46PFL4908K/12
46PFL3108K/12
60PFL6008K/12
46PFL8007K/12
32PFL4258K/12
37PFL3507K/02
39PFL3208K/12
47PFL7108/12
39PFL4208K/12
55PFL7008K/12
46PFL8008S/12
46PFL3807
22PFL2908
47PFL5038K/12
50PFL4208K/12
42PFL3704
24PFL4008K/12
42PFL3218K
24PFL3108H/12
22PFL4008K/12
46PFL4208K/12
55PFL7108K/12
55PFL8008S/12
24PFL4228K/12
47PFL5008K
50PFL7956K
47PFL6008K
32PFL3807H
40PFL5507H
42PFL5008K
39PFL3807H
55PFL5507H
37PFL7606H/12
40PFL7007K/12
40PFL5007K/12
42PFL3507H/12
42PFL4007K/12
40PFL5206H/12
40PFL6606H/12
37PFL4007K/12
37PFL6606H/12
47PFL4007K/12
47PFL6007H/12
46PFL7007H/12

32PFL3507H/12
55PFL5507K/12
40PFL9606K/02
40PFL8606H/12
32PFL7406H/12
32PFL6606H/12
32PFL5507H/12
32PFL5007K/12
32PFL4007L/12
32PFL3017H/12
42PFL3007H/12
24PFL4208K/12
32HFL5107H/10
32PFH5509
32PFL3258K/12
40PFL3208K
40PFL4418K/12
40PFL4508K/12
42PFL7008K/12
42PFL7108K/12
46PDL8908S/12
46PFL3208K/12
46PFL4528K/12
47PFL6158K/12
50PFL3807K
55PFL5537K/12
55PFL6008K/12
55PFL6198K/12
60PFL9607S/12
32PFL3208H
32PFH4109
40PFH5509
40PFH4509
40PFL8808S/12
42PFH6109
42PFL4208H/12
42PFL5038K/12
42PFL6188K/12
47PFL5028K/12
48PFH5509
55PFL6158K
55PFL4908L/12

Sharp

Modelle

LC-39LE752
LC70LE747E
LC39LE752E
LC-80LE657E
LC-39LE352-BK

LC-70LE747
LC-22LE240E
LC-39LE352E-WH
LC-32LE630E
LC-32LE632E
LC-46LE632E
LE-39LE752E
LC-39LE652E
LC-22LE250E
LC-32LE352E-WH
LC-40LE632E
LC-60LE635E
LC-60LE840E
LC-70LE857E
LC-70LE835E
LC-80LE857E
LC-50LE752E
LC-50LE652E
LC-60LE857E
LC-60LE752E
LC-60LE652E
LC-42LE761E
LC-50LE760E

Sony

Modelle

KDL-32W651
KDL-40R485
KDL-42W805A (only Mouse)
KDL-42W807A
KDL-32W656
KDL-46R470
KDL-50W656A
KDL-42W656
KDL-55W805A (only Mouse)
KDL-50W685
KDL-55W905A (only Mouse)
KDL-32W655
KDL-65W855A
KDL-42W655
KDL-24W605A
KDL-32W605A
KDL-55W807A
KDL-40W905A (only Mouse)
KDL-47W805A (only Mouse)
KDL-47W807A
KDL-55EX710
KDL-65HX925
KDL-22EX310
KDL-46HX755

KDL-46EX655
KDL-55HX755
KDL-55HX955
KDL-40EX721
KDL-40EX655
KDL-40HX755
KDL-32EX721B
KDL-32W705
KDL-40EX650
KDL-40W605B
KDL-42W705
KDL-60W605B
KDL-42W829
KDL-42W706B
KDL-60W855B

Thomson

Modelle

1. 55FW6765/G
2. 40FW5555/G
3. 50FW5563/G

Note

The mouse and keyboard function works on all televisions that support a mouse and keyboard input. Please contact your TV manufacturer about the compatibility. Due to the variety of television sets and the installed firmware and apps, we cannot give 100% compatibility at all times

Samsung

2012 Models

- Samsung Series 5 EH5300
- Samsung Series 5 ES5400
- Samsung Series 5 ES5410
- Samsung Series 5 ES5500
- Samsung Series 5 ES5700
- Samsung Series 6 ES6100
- Samsung Series 6 ES6300
- Samsung Series 6 ES6340
- Samsung Series 6 ES6570
- Samsung Series 6 ES6710
- Samsung Series 6 ES6800
- Samsung Series 6 ES6900
- Samsung Series 8 ES8000

2013 Models

- UE55F9000SLXXN
- UE65F9000SLXXN
- UE55F8500SLXXN
- UE65F8000SLXXN
- UE55F8000SLXXN
- UE46F8000SLXXN
- UE40F8000SLXXN
- UE60F7000SLXXN
- UE46F7000SLXXN
- UE40F7000SLXXN
- UE55F6400AWXXN
- UE50F6400AWXXN
- UE46F6400AWXXN
- UE40F6400AWXXN
- UE32F6400AWXXN
- UE50F6200AWXXN
- UE46F6200AWXXN
- UE40F6200AWXXN
- UE32F6200AWXXN
- UE50F5700AWXXN
- UE46F5700AWXXN
- UE42F5700AWXXN
- UE32F5700AWXXN
- UE39F5700AWXXN
- UE50F5500AWXXN
- UE46F5500AWXXN
- UE39F5500AWXXN
- UE32F5500AWXXN
- UE42F5500AWXXN
- UE22F5410AWXXN
- UE22F5400AWXXN
- UE42F5300AWXXN

- UE32F5300AWXXN
- UE39F5300AWXXN
- UE46F5300AWXXN
- UE32F4510AWXXN
- UE40F6740SSXXN
- UE55F6670SSXXN
- UE50F6670SSXXN
- UE46F6670SSXXN
- UE40F6670SSXXN
- UE55F6650SSXXN
- UE46F6650SSXXN
- UE40F6650SSXXN
- UE55F6640SSXXN
- UE50F6640SSXXN
- UE46F6640SSXXN
- UE40F6640SSXXN
- UE55F6510SSXXN
- UE46F6510SSXXN
- UE40F6510SSXXN
- UE32F6510SSXXN
- UE55F6500SSXXN
- UE50F6500SSXXN
- UE46F6500SSXXN
- UE40F6500SSXXN
- UE75F6400AWXXN
- UE65F6400AWXXN
- UE55F6400AWXXN
- UE46F6400AWXXN
- UE40F6400AWXXN
- UE32F6400AWXXN
- UE55F6320AWXXN
- UE46F6320AWXXN
- UE40F6320AWXXN
- UE60F6300AWXXN
- UE46F6200AWXXN
- UE40F6200AWXXN
- UE32F6200AWXXN
- UE46EH5300WXXN
- UE32F4510AWXXN

2014 Models

- UE75HU7500LXXN
- UE65HU7500LXXN
- UE55HU7500LXXN
- UE48HU7500LXXN
- UE55HU6900SXXN
- UE50HU6900SXXN
- UE40HU6900SXXN
- UE85S9SLXXN
- UE78HU8500LXXN (Curved)
- UE65HU8500LXXN (Curved)

- UE55HU8500LXXN (Curved)
- UE65H8000SLXXN (Curved)
- UE55H8000SLXXN (Curved)
- UE48H8000SLXXN (Curved)
- UE50H6200AWXXN
- UE48H6200AWXXN
- UE40H6200AWXXN
- UE32H6200AWXXN
- UE22H5610AWXXN
- UE22H5600AWXXN
- UE48H5570SSXXN
- UE40H5570SSXXN
- UE32H5570SSXXN
- UE65HU8200L
- UE55HU8200L
- UE55HU7200S
- UE65HU7100S
- UE55HU7100S
- UE55H6850A
- UE48H6850A
- UE55H6800A
- UE48H6800A
- UE85HU7500L
- UE65HU7200S
- UE55HU7200S
- UE65HU7100S
- UE55HU7100S
- UE60H7000SL
- UE55H7000SL
- UE46H7000SL
- UE40H7000SL
- UE55H6700SL
- UE48H6700SL
- UE40H6700SL
- UE55H6670SL
- UE48H6670SL
- UE40H6670SL
- UE55H6650SL
- UE48H6650SL
- UE48H6640SL
- UE40H6650SL
- UE55H6640SL
- UE40H6640SL
- UE55H6500SL
- UE48H6500SL
- UE40H6500SL
- UE55H6410SS
- UE48H6410SS
- UE40H6410SS
- UE32H6410SS
- UE75H6400AW

- UE65H6400AW
- UE55H6400AW
- UE50H6400AW
- UE48H6400AW
- UE40H6400AW
- UE48H6240A
- UE40H6240A
- UE60H6230A
- UE55H6230A
- UE60H6203A
- UE55H6203AW
- UE46H6203AW
- UE40H6203AW
- UE60H6200AW
- UE55H6200AW
- UE48H5510S
- UE40H5510S
- UE50H5500AW
- UE48H5500AW
- UE40H5500AW
- UE32H5500AW
- UE46H5303AW
- UE40H5303AW
- UE32H5303AW
- UE58H5203A
- UE48H5203A
- UE40H5203A

2014 & 2015 Models

- J5550 (5er, 6er-Serie, no J5150)
- H6270 (6er, 7er, 8er-Serie)

Grundig

Models

42 VLE9380 SL
 46 VLE880
 32 VLE8230 WL
 55 VLE9380 SL
 40 VLE 7320 BL
 40 VLE7321 BL
 39 CLE2525 BL
 32 VLE8120 BG
 55 FLE9170 SL
 42 VLE9474 SL
 39 VLE941
 40 VLE8221 BL

LG Electronics

2012 Models

47LA7909
 50PH6608
 47LA7408
 60PH6608
 32LA6208
 50PH6708
 47LA6418
 42LA6418
 55LA6608
 47LA6136
 32LA6678
 42LN5758
 55LA7408
 42LA6208
 32LA6608
 50LN5758
 42LA6678
 29LN450
 32LN5758
 42LA6918
 42LN5700
 32LN5403
 47LA6678
 47LA8609
 60LA8609
 55LA6678

47LA6208
 55LA7909
 55LA6918
 50LA6608
 55EA9809
 42LA6928
 32LA6130
 47LA6918
 42LA8609
 42LA620S
 55LA6418
 42LN5778
 55LA6208
 55LA9709
 32LN5778
 55LN5758
 84LM960V
 47LM765S
 55LM649S
 60PZ955S
 50PZ755S
 55LM765S
 42LA6608
 47LA6608
 42LV5590
 37LV579S
 72LM950V
 55LM660S
 55LM640S
 39LN5758
 47LB630V
 50LA6208
 32LB580V
 50LN5708
 50LB671V
 60LA6208
 32LB560V
 47LN5708
 39LB570V
 65LA9709
 42LD320B
 47LN5778
 42LB731V
 60LN5758
 60LB650V
 55LB671V
 47LB730V

42LB630V
 42LB671V
 47LN5758
 55LB630V
 32LB5610
 39LB650V
 50LB650V
 55LA9659
 47LB671V
 28LB450U
 60LB870V
 42LA4708
 47LN5778
 42LB730V
 42LB650V
 42LN5708
 47LB731V
 55LB731V
 55LB670V
 55EA8809
 55LB650V
 55EA9709
 55LB870V
 60LB580V
 65LA9659

Loewe

Models

Connect ID 55
 Connect ID 46/DR+
 Connect ID 40
 Connect ID 46
 Connect ID 32
 Connect ID 40 DR+
 Art 40

Panasonic

Models

TX-L42E6E
 TX-L47E5E
 TX-L50BLW6
 TX-L50BLW6
 TX-P50X60E
 TX-P42X60
 TX-L42EW6K
 TX-L39EW6K
 TX-L39EW6W
 TX-L42E5E
 TX-L42EW6S
 TX-L39BLW6
 TX-L32BLW6
 TX-L55ETW60
 TX-L42ETW60
 TX-L47ETW60
 TX-L50ETW60
 TX-L50DTW60
 TX-L55DTW60
 TX-L60DTW60
 TX-L24XW6
 TX-L42DTW60
 TX-L47DTW60
 TX-39ASW604
 TX-24ASW504
 TX-42ASW604W
 TX-42ASW654
 TX-47ASW654
 TX-55ASW654

Philips

Models

50PFL5038K/12
 32PFL4508K/12
 47PFL7008K/12
 42PFL6008K/12
 46PFL3218K
 46PFL4908K/12
 46PFL3108K/12
 60PFL6008K/12
 46PFL8007K/12
 32PFL4258K/12
 37PFL3507K/02
 39PFL3208K/12
 47PFL7108/12
 39PFL4208K/12
 55PFL7008K/12
 46PFL8008S/12
 46PFL3807
 22PFL2908
 47PFL5038K/12
 50PFL4208K/12
 42PFL3704
 24PFL4008K/12
 42PFL3218K
 24PFL3108H/12
 22PFL4008K/12
 46PFL4208K/12
 55PFL7108K/12
 55PFL8008S/12
 24PFL4228K/12
 47PFL5008K
 50PFL7956K
 47PFL6008K
 32PFL3807H
 40PFL5507H
 42PFL5008K
 39PFL3807H
 55PFL5507H
 37PFL7606H/12
 40PFL7007K/12
 40PFL5007K/12
 42PFL3507H/12
 42PFL4007K/12
 40PFL5206H/12
 40PFL6606H/12
 37PFL4007K/12
 37PFL6606H/12
 47PFL4007K/12
 47PFL6007H/12
 46PFL7007H/12

32PFL3507H/12
 55PFL5507K/12
 40PFL9606K/02
 40PFL8606H/12
 32PFL7406H/12
 32PFL6606H/12
 32PFL5507H/12
 32PFL5007K/12
 32PFL4007L/12
 32PFL3017H/12
 42PFL3007H/12
 24PFL4208K/12
 32HFL5107H/10
 32PFH5509
 32PFL3258K/12
 40PFL3208K
 40PFL4418K/12
 40PFL4508K/12
 42PFL7008K/12
 42PFL7108K/12
 46PDL8908S/12
 46PFL3208K/12
 46PFL4528K/12
 47PFL6158K/12
 50PFL3807K
 55PFL5537K/12
 55PFL6008K/12
 55PFL6198K/12
 60PFL9607S/12
 32PFL3208H
 32PFH4109
 40PFH5509
 40PFH4509
 40PFL8808S/12
 42PFH6109
 42PFL4208H/12
 42PFL5038K/12
 42PFL6188K/12
 47PFL5028K/12
 48PFH5509
 55PFL6158K
 55PFL4908L/12

Sharp

Models

LC-39LE752
 LC70LE747E
 LC39LE752E
 LC-80LE657E

LC-39LE352-BK
 LC-70LE747
 LC-22LE240E
 LC-39LE352E-WH
 LC-32LE630E
 LC-32LE632E
 LC-46LE632E
 LE-39LE752E
 LC-39LE652E
 LC-22LE250E
 LC-32LE352E-WH
 LC-40LE632E
 LC-60LE635E
 LC-60LE840E
 LC-70LE857E
 LC-70LE835E
 LC-80LE857E
 LC-50LE752E
 LC-50LE652E
 LC-60LE857E
 LC-60LE752E
 LC-60LE652E
 LC-42LE761E
 LC-50LE760E

Sony

Models

KDL-32W651
 KDL-40R485
 KDL-42W805A (only Mouse)
 KDL-42W807A
 KDL-32W656
 KDL-46R470
 KDL-50W656A
 KDL-42W656
 KDL-55W805A (only Mouse)
 KDL-50W685
 KDL-55W905A (only Mouse)
 KDL-32W655
 KDL-65W855A
 KDL-42W655
 KDL-24W605A
 KDL-32W605A
 KDL-55W807A
 KDL-40W905A (only Mouse)
 KDL-47W805A (only Mouse)
 KDL-47W807A
 KDL-55EX710
 KDL-65HX925
 KDL-22EX310

KDL-46HX755
 KDL-46EX655
 KDL-55HX755
 KDL-55HX955
 KDL-40EX721
 KDL-40EX655
 KDL-40HX755
 KDL-32EX721B
 KDL-32W705
 KDL-40EX650
 KDL-40W605B
 KDL-42W705
 KDL-60W605B
 KDL-42W829
 KDL-42W706B
 KDL-60W855B

Thomson

Models

55FW6765/G
 40FW5555/G
 50FW5563/G